



EB+ **DIAG+**
V 4.14

USER GUIDE



000 700 255 / 07.05. / Redditch



Contents

Introduction	Page 2
Minimum System Specification	Page 2
Installation	Page 3
The hardware	
The software	
Running DIAG+	
Connections - Semi, Centre axle Trailers	Page 4
Connections - Full Trailers	Page 5
Secondary Displays	Page 6
Setting system parameters	Page 7
ECU Configuration	Page 7
Load Plate Data entry	Page 10
- Semi, Centre axle Trailers	
Load Plate Data entry - Full Trailers	Page 11
Setting Auxiliaries	Page 12
Setting Wheel Scaling	Page 17
Test for Number of Teeth	Page 17
Lamp Settings	Page 17
Info - Trailer Information	Page 18
Save the ECU Parameters	Page 19
Load plate label	Page 20
- Semi, Centre axle and Full Trailers	
Setting the Trailer EBS warning lamp	Page 21
Reading/deleting diagnostic codes	Page 22
Reading Extended DTC's	Page 23
Reading Lining Wear Sensor	Page 24
Reading Modification Record	Page 25
Reading system pressures, speeds and voltage	Page 26
End-Of-Line Test Procedure	Page 27
End-of-Line Test Report	Page 30
Diagnostics Trouble Codes (DTC)	Page 31
Troubleshooting	Page 34

Introduction



With **DIAG+** you can use a standard personal computer to read and delete diagnostic codes, program vehicle parameters and End-of-line-Test the **EB+** system. The PC Interface pod is the hardware to allow communications between a standard PC and a number of diagnostic interfaces. Connections to the PC interface are done through a 9 to 25 way cable connecting to the RS232 port on the computer and a additional cable connecting the diagnostic interface pod to the ECU. A USB to Serial converter can be used - recommended type 'Roline' (RS 450-3238). The vehicle parameter data is stored inside the **EB+** ECU. It will remain intact even after electrical power is removed from the **EB+** system.

NB: EB+ Interface Pod is different to the Interface Pod as used on MODAL / MODULAR ABS systems.

Minimum system specification

The minimum PC or Laptop specification to run the **DIAG+** package is as follows:

- ◆ Processor - 486 or above
- RAM - 8 Megabytes (16 recommended)
- Hard Drive - 20 Megabytes
- Monitor - 640 x 480 VGA Minimum

- ◆ MS Windows 95, 98, ME, XP, NT and 2000

In addition to the above, a CD drive is required for software installation and COM serial port required to connect to the interface pod.

The hardware

The **DIAG+** Interface kit is comprised of the PC Interface pod, together with its connecting cables and a transit case.

The pod is provided with a multi function LED to confirm correct function of the unit as follows:



Red: To indicate that 24V power is connected to the **EB+** ECU.

Green: To indicate data is being transmitted.

NB: During connection the Red and Green alternate.


Installation Option 1

Gently push the plug '1' into the COM port socket on the back of your PC or Laptop and tighten the screws. Push the GREEN plug '2' into the **EB+** ECU socket marked 'DIAG'.



Installation Option 2

Gently push the plug '1' into the COM port socket on the back of your PC or Laptop and tighten the screws. Push plug '2' into the **EB+ Diagnostic socket** located on the chassis.



Power the **EB+** system from an external 24V supply and the LED light on the interface pod should now be on, coloured red. If it is not, please check your connections and try again.

The software

NB: It is possible to install the software without connecting the **DIAG+** hardware although no data will be available.

Switch on your machine and enter into the desktop mode of your PC. Insert the **DIAG+** CD into your PC. Follow the on screen instructions to install the program in the relevant Language.

NB: For **DIAG+** to work, your **EB+** system **MUST** be connected and powered by an ISO7638 power supply.

The files are installed in the PC folder :

C:\Program Files\Haldex\Diag+

Also Sub folders are installed as follows :

C:\Program Files\Haldex\Diag+\DTC Reports

C:\Program Files\Haldex\Diag+\ECU Setup files

C:\Program Files\Haldex\Diag+\EOLT Reports

Installation is now complete.

Please keep your installation software in a safe place in case you need to reinstall at any point.

ECU Connections - Semi, Centre axle Trailers

Make all required connections to the ECU


- 3 - Power supply ISO7638.....
 - 4 - Pressure switch PSW.....
 - 5 - Sensor S1A.....
 - 6 - Sensor S1B.....
 - 7 - Sensor S2A
 - 8 - Sensor S2B
 - 9 - AUX1
 - 10 - AUX2
 - 11 - AUX3
 - 12 - AUX4
 - 13 - AUX5
 - 14 - Backup power supply ISO1185 (24N)
- } Minimum required for a 2S/2M system
- } See page 12 for Options

NB: It is possible to use the DIAG+ software to set the ECU parameters with only the power supply ISO7638 connected, i.e. without any other connections 4 to 14, but diagnostic codes will be logged and will require to be deleted on final vehicle installation.

Power up the EB+ ECU. During the self-check procedure the system displays the following functions:

- 1 - The Trailer EBS warning lamp comes ON and stays ON.
- 2 - One audible cycle is produced by the EPRV's (EBS valves).

At the same time the LED on the PC interface pod will illuminate 'RED/GREEN' to show that it is receiving a power supply from the ECU.




Red/Green LED

Enter into the **DIAG+** program by the short-cut icon '15' created on your desktop. The following 'Normal' screen '16' should appear (See page 6 for secondary main screen displays).




15



16

Understanding the main screen display

- 17 - Browser window (e.g.. EB+ System layout (EOLT))
- 18 - Video screen
- 19 - 'End-of-line Test' (EOLT) procedure
- 20 - Reset the ECU
- 21 - Exit the **DIAG+** program
- 22 - Cab Lamp (Pin 5 - ISO7638) indicator
- 23 - Read, Setup and Program the ECU
- 24 - Read/Delete Diagnostic Trouble Codes (DTC)
- 25 - PC connection port indication
- 26 - Interface Version number
- 27 - **EB+** ECU Version number
- 28 - Odometer reading (Total distance) and
- 29 - Chassis Number



ECU Connections - Full Trailers



Make all required connections to the Master ECU

- 3 - Power supply ISO7638.....
 - 4 - Interconnecting cable.....
 - 5 - Pressure switch PSW.....
 - 6 - Sensor S1A.....
 - 7 - Sensor S1B.....
 - 8 - Sensor S2A.....
 - 9 - Sensor S2B.....
 - 10 - AUX1
 - 11 - AUX2
 - 12 - AUX3
 - 13 - AUX4
 - 14 - AUX5 - Not Available
- } Minimum required for a 4S/3M system
- } See page 7 for Options


Make connection to the Slave ECU

- 4 - Interconnecting cable..... Minimum required

NB: It is possible to use the DIAG+ software to set the ECU parameters with only the power supply ISO7638 and Interconnection cable (Master to Slave ECU) connected, i.e. without any other connections 5 to 14, but diagnostic codes will be logged and will require to be deleted on final vehicle installation.




On entering into the **DIAG+** program the following 'Normal' screen should appear (See page 6 for secondary main screen displays).




Secondary main screen displays

A flashing 'Warning' symbol indicates EB+ system warning. This alternates with the following symbols:-



A flashing 'Spanner' symbol. This indicates presence of a 'Active' Diagnostic Trouble Code.


Click on button  '24' to Read/Delete DTC.



24


A flashing 'Gauge' symbol. This indicates the reservoir pressure is below 4.5 bar.

NB: End of line Test reservoir pressure requires to be 1 bar above laden brake output pressure to the Trailer.




Setting System Parameters

Click button '23' Read, Setup and Program the ECU
The following screen will appear.



Understanding the screen display

- 30 - Read ECU Configuration from disc
NB: To read this file you must enter the 'Edit' ECU parameters section (32).
- 31 - Read Configuration info. from ECU
NB: To read this file you must enter the 'Edit' ECU parameters section (32).
- 32 - Edit ECU parameters and Configuration
- 33 - Save ECU Configuration to disc
- 34 - Program ECU with current Configuration info.
- 35 - Print current ECU Configuration information - Load Plate
- 36 - OK - Exit the 'Program ECU' menu




To edit the ECU parameters and Configuration click on button '32'.



The following screen will appear.

Understanding the screen display

- 37 - Setup the ECU configuration and layout
- 38 - Setup loadplate configuration
- 39 - Display trailer information
- 40 - Setup aux configuration data
- 41 - Setup wheelscale configuration
- 42 - Setup lamp flash configuration
- 43 - OK - Exit the ECU setup



ECU Configuration

Click on button '37' on the ECU setup screen.



The following (1 of 6) screen will appear.

- a) 2M Side x Side
- b) 1M
- c) 2M Axle x Axle
- d) 2M Non Integrated
- e) 3M Full Trailer
- f) 3M Semi Trailer

The configuration group title is shown at the top right of the screen in which below are left and right arrow boxes to enable to toggle between the configuration screens. See page 8-9 for further screen layouts.

Click on one of the boxes on the left side of the table selecting your system layout. A view on the right side of the table is the chosen ECU configuration and layout.

Click on button marked ✓ to accept.


NB: The ECU Configuration has a default setting of: 3 Axle trailer, 2 Sensors on centre axle, ECU left hand installation.

If box '44' is selected this adjusts the working parameters in the absence of a REV.

If box '45' is selected (as shown) this adjusts the working parameters in the presence of a REV.


If box '46' is selected (as shown) Load Sensing function is available together with ABS on Backup powering (ISO1185 (24N)).

If box '47' is selected (as shown), any automatic lift axles will not raise until move away (when the lamp goes out). It is to enable roller testing of all axles even when unladen. (**NB:** Use for the UK vehicle test authority).




1M configuration screen.


NB: Position of ECU can be left, right, front or rear.




2M Axle x Axle configuration screen.




2M Non Intergrated configuration screen.



3M Full Trailer configuration screen.




3M Semi Trailer configuration screen.



Click on button marked ✓ to accept.

The following screen will appear.



Load Plate Data entry

Click on button



For Semi and Centre axle Trailers the following screen will appear.

The screen shows a set of default values (1 to 5 and 10 to 12) which require to be entered in accordance to the vehicles brake calculation.

Highlighting the appropriate box enables you to edit the value or pressing the tab button on your PC will step through, one by one, the various boxes to be edited or selected.

The following example shows values entered from a HALDEX brake calculation as shown below.





NB: If values 6, 7, 8, and 9 are required (see brake calculation example below) To enter the values click on Use boxes.

6	<input checked="" type="checkbox"/> Use	PP1 (Control)	1.60	7	PP1 (Delivery) Laden	1.20
8	<input checked="" type="checkbox"/> Use	PP2 (Control)	3.00	9	PP2 (Delivery) Laden	2.60

If value 'P Limit' is required, this limits the pressure at the brake chambers to the value selected which must be ≥ 5.00 bar (**NB:** not derived from brake calculation). To enter the values click on Use P Lim box (default value is 8.50 bar).

Click on button marked to accept.

The graph shows the brake demand pressure (INPUT) values are in relation to the brake delivery pressure (OUTPUT) values.



Haldex brake calculation

Input datas for the EBS-Modulator EB+:						3	4					
		control pr. pm		6.50 bar		control pr. pm						
Axle	Axle load unladen (Kg)	Bag press. unladen (bar)	Brake press. unladen (bar)	Axle load laden (Kg)	Bag press. laden (bar)	Brake press. laden (bar)	5	7	9	11		
		1	12		2		6	8	10			
1	1150	0.60	1.75	8000	4.30	0.00	0.30	1.20	2.60	5.90	bar	
2	1150	0.60	1.75	8000	4.30	0.00	0.30	1.20	2.60	5.90	bar	
3	1150	0.60	1.75	8000	4.30	0.00	0.30	1.20	2.60	5.90	bar	

NB: Items 6,7,8,and 9 vary according to Brake calculation (i.e. Drum brakes to Disc brakes)

Load Plate Data entry

For Full Trailers the following screen will appear.

The screen shows a set of default values For a Master and a Remote ECU which require to be entered in accordance to the vehicles brake calculation.

The following examples shows values entered from a HALDEX brake calculation as shown below.

Click on button marked to accept

Haldex brake calculation - Master ECU

Input datas for the EBS-Modulator EB+:

				<div style="display: flex; justify-content: space-around;"> 3 P0 4 PD 10 P3 </div>		
RAG	control pr.	pm	6.50 bar	control pr.	pm	<div style="display: flex; justify-content: space-around;"> 0.40 0.70 6.50 bar </div>
Axle	Axle load unladen (Kg)	Bag press. unladen (bar)	Brake press. unladen (bar)	Axle load laden (Kg)	Bag press. laden (bar)	Brake press. laden (bar)
		1	12		2	<div style="display: flex; justify-content: space-around;"> 5 11 </div>
1	1700	0.55	2.10	9000	3.50	0.00 0.40 6.85 bar

Click on button marked to accept

Haldex brake calculation - Remote ECU

Input datas for the EBS-Modulator EB+:

				<div style="display: flex; justify-content: space-around;"> 3 P0 4 PD 6 P1 8 P2 10 P3 </div>				
FAG	control pr.	pm	6.50 bar	control pr.	pm	<div style="display: flex; justify-content: space-around;"> 0.40 0.70 2.00 2.50 6.50 bar </div>		
Axle	Axle load unladen (Kg)	Bag press. unladen (bar)	Brake press. unladen (bar)	Axle load laden (Kg)	Bag press. laden (bar)	Brake press. laden (bar)		
		1	12		2	<div style="display: flex; justify-content: space-around;"> 5 7 9 11 </div>		
1	2350	0.90	2.10	10000	4.03	0.00 0.40 1.40 2.50 6.85 bar		

Setting Auxiliaries

The following parameters have default settings as shown below :

Auxiliaries - Not used (Unused)

Wheel Scaling - 306 rev/KM, 520 Rdyn (mm) and 100 No. of teeth exciter



Lamp Sequence - ON/OFF

If these are correct go to page 18 (Trailer information)

Click on button

The following screen will appear.


The screen shows the various Auxiliary connections that can be used (i.e. AUX 1 to 3, 4 and 5). Clicking on arrow '48' displays a listing of options that can be selected.




Selecting options

COLAS (on Aux 1)

Highlight option and click to select it. The required parameters for that option are automatically set.



To view the set parameters click on button marked Modify '49'.




Example COLAS (AUX 1.2 & 3)

The following screen will appear modify the values as required.

- Duration : Time Colas solenoid is energised (Default 5s)
- On Speed : The output to the Colas will be switched ON (Default 15 Kph)
- Off Speed : The output will be switched OFF either when the vehicle decelerates below the 'Off Speed' or when 'Duration' has been exceeded, whichever happens first. (Default 0 Kph)

NB: By setting the 'Duration' to 0 sec. this now becomes a speed signal and a 'On and Off Speed' has to be set.



Click on button marked to accept.

Example ILAS®-E (AUX 1.2 & 3)

Auto raise / auto lower.

The following screen will appear, modify the values as required.

Drop : The pressure where the ILAS solenoid is de-energised resulting the axle to drop.
(Default - 90% of Laden suspension pressure)


Raise : The pressure where the ILAS solenoid is energised resulting for the axle to raise.
(Default - 50% of Laden suspension pressure)

Sensor Configuration : Disables the wheel speed signal when a sensed axle is raised.
(Default - Not Sensed)

Raise with speed, Drop with speed are further options that can be selected when the drop and raise pressures are reached.

NB: For installations with ILAS®-E use:

- ◆ Front lift axle only = **ILAS-E Front**
- ◆ Middle lift axle only = If lifting it weights the king pin then **ILAS-E Front**
- ◆ Rear lift axle only = **ILAS-E Rear**
- ◆ Two axles lifted
i.e. Front and Rear = **ILAS-E Front + ILAS-E Rear**



Example ILAS®-E Manual (AUX 2 & 3)


Manual = Manual raise / auto lower. Requires a 24V signal/switch on the yellow wire of the 3 core AUX cable. The following screen will appear, modify the values as required.

Drop : The pressure where the ILAS solenoid is de-energised resulting the axle to drop.
(Default - 90% of Laden suspension pressure)

Raise : The pressure where the ILAS solenoid is energised resulting for the axle to raise.
(Default - 50% of Laden suspension pressure)

Sensor Configuration : Disables the wheel speed signal when a sensed axle is raised. (Default - Not Sensed)

Raise with speed, Drop with speed Options are not valid.




Example Steer Axle Lock (AUX 1.2 & 3)

The following screen will appear modify the values as required.

Lock Above : Speed at which the steer axle locks
(Default 25 Kph)

Unlock : Speed at which the steer axle unlocks
(Default 20 Kph)

Lock Unless Front Axle Lifted : The steer axle is set to lock and unlocks when the front axle is lifted in order to maintain turning circle.




**Example Overload Lamp (AUX 1,2 & 3)
For Semi / Centre axle Trailers**

This gives a 24V output when the trailer load goes above the set limits. The following screen will appear modify the values as required.

NB: Overload lamp works with ONLY THE MAIN (master ECU) Valve suspension Input.

For Full trailers see 'Remote Overload Lamp' Page 16



Lining Wear Lamp (AUX 1,2 & 3)


This gives a 24V output to a warning lamp when a lining wear sensor is worn.

NB: This can only be selected after AUX 4 Option

AUX 4 - Option

Select 'Lining Wear Sensor'

To view extra options and parameters click on button marked Modify on 'AUX 4' line.




The following screen appears.

From the menu 'Select LWI Hardware' select type required from the pull-down menu. 'Haldex LWI' and 'BPW Brake Monitor' are pre-programmed options and no other data is required.

'Custom' allows entry of user settings (see Custom screen below).


The 'Service Lamp Flash' is set as default. A sequence of three lamp flashes on ECU power up.

'Continuous Flash' causes the flashing to continue until the vehicle is first driven away from rest.



The Custom screen allows the user to enter custom voltage settings as to an alternative manufacturer lining wear system used.

N.B. As the pads wear the input voltage can rise or drop. If the lining wear sensor is tampered (i.e. short circuited) the input voltage rises.




Lateral Accelerometer (EB+ Stability) for 2M Systems ONLY

Support for External Accelerometer

AUX 5 - Option

On the following ECU part Nos.
812 001 301 Version A256 or later
812 001 201 Version A256 or later
 This AUX Configuration must be used.


Select 'Lateral Accelerometer' to calibrate EB+ Stability.




Support for Internal Accelerometer

On the following ECU part Nos.
812 013 001
812 012 001
 This AUX Configuration must be used.

To set the parameters click on button '51' marked 'Internal'



The following screen will appear.
 Click on box '52' to select Internal Accelerometer Installation.
NB: A additional Auxiliary test runs specifically for the Internal Accelerometer (see page 29 'INT' test)



Reaction to Various Configuration Possibilities

Make sure the correct Aux Configuration is chosen i.e. External mounted on **AUX 5** or **Internal** (within the ECU).


Errors that will occur are as follows:

- Accelerometer will not work.
- A stability sensor DTC will be recorded.

Extra Lift Axle data menu

To view a set of parameters click on button marked 'Modify' '50'.

The following screen will appear.



Raise Speed

If the option RAISE WITH SPEED is set for ANY lift axle, then the axle will not lift before the set speed (The default is 50 km/h).

Example is for manoeuvring before getting on to the highway.

Drop Speed


If the option DROP WITH SPEED is set for ANY lift axle, then the axle will drop automatically the vehicle speed falls below the set speed (The default is 1 km/h).

Traction Overload limit

The Traction Assist axle will drop once the suspension reaches this value, based on % of laden setting. An INFORMATION icon is displayed above 130% to ask the user to check the design weights for the remaining axle(s) as the legal limit is 130% of design weight. (The default is 130%).

Traction Speed limit

The Traction Assist axle will drop once the vehicle speed increases above the value (The default is 25 km/h). A warning icon is displayed above 30 km/h to indicate that this is above the legal limit.




Action on 5 sec Press

Normally, when the Lift Axle Switch has been pressed for 5 s, the system assumes that the switch is a PERMANENT type, not a MOMENTARY type. If this option is selected then the system will ALWAYS assume that the switch is MOMENTARY and will disable (lower) all lift axles until the system is next re-powered (ignition off).

**Remote Overload Lamp (AUX 1,2 & 3)
For Full Trailers (4S/3M system)**

This gives a 24V output when the trailer load goes above the set limits, and off below Lower limit. The following screen will appear modify the values as required.

NB: Remote overload lamp works with ONLY THE REMOTE (slave ECU) Valve suspension Input.



Setting Wheel Scaling



Click on button

The following screen will appear.

The screen shows the default value of a tyre size of 306 revs/km, 520 Rdyn (Dynamic rolling radius - mm) with a 100 tooth exciter installed. This value covers tyre sizes from 19.5" to 22.5" and sets the correct ABS function and odometer of the system.

NB: If the tooth number is not 100 the wheel scale factor on the Info Centre will read a different value.

Click on button marked to accept.



Test for number of teeth

Click on button

Click on button marked **'Start - Turn Wheel 5 Times'**
Rotate the Selected wheel 1 rev / 2sec, five times.
The Pulses box automatically records during the wheel rotation procedure.



After 5 turns, click on button marked **'Stop'**

The **'No. Of Teeth'** box indicates the value.

Click on button marked **'Use Calculated Value'** if required to use in wheel scaling above or note the value for information purposes.

Click on **'Abort'** to exit.

Repeat for any other selected sensor



Lamp Settings

Click on button



The following screen will appear.

The screen shows the two options of flash sequence for the trailer EBS warning lamp.

The ON/OFF sequence is set as a default.


Click on button marked to accept.

NB: The ON/OFF lamp sequence change will only be visible if system air pressure is above 4.5 bar.



Info - Trailer information

Click on button



The following screen will appear.

Enter details of :

Trailer Manufacturer (19 characters)

Brake Calculation Number (16 characters)

Chassis Number (17 characters)

Type (12 characters)

Axle Information - Load of axle/s installed on the trailer.
(Default values are: Unladen =3000 Kg, Laden=9000Kg)


This information is stored in the ECU and can be printed out on the End-of-line Test report and load plate.

Click on button marked to accept.

Unladen			Laden		
Axle 1	3000	Kg	Axle 1	9000	Kg
Axle 2	3000	Kg	Axle 2	9000	Kg
Axle 3	3000	Kg	Axle 3	9000	Kg

'ECU setup' is complete (ECU parameters settings **not sent to ECU** - see next step).

Click on button marked to accept.



Saving the ECU parameters

OPTION 1

Saving the ECU parameters file to disc

Click on button



The following screen will appear. A file name (e.g. EXAMPLE 01 saved as type .DPT) can be entered in position 'File Name' and stored in the **C:\Program Files\Haldex\Diag+\ECU Setup files** folder.

Click on button 'Save' to store the file.

NB: The saved EB+ ECU parameter file can be used for future programming of ECU's (which require the same parameters) by recalling the file from the 'Open EB+ ECU File' button (number '30' see page 7).

OPTION 2

Programming the ECU

Click on button



This activates the sending of the

edited parameters file to the ECU.

NB: At 90% progress all the DTC's are deleted and the ECU is reset.

The status of this process is shown in the following ways:

- 53 - A bar indicator fills the progress box on the 'Program ECU' screen
- 54 - The trailers EBS warning lamp function is -
 - a) ON - ECU not programmed
 - b) FLASHING - programmed ECU (with an 'ECU setup' installed)

NB: The trailers EBS warning lamp is ON






This completes the programming of the ECU.

The following screen will appear.

Click button



current ECU configuration information (Load plate label).




Print label using Haldex blank label 028 5301 09.

Use Laser printer only and refer to manufacturers information on printing a A5 size paper. After installation spray on a clear lacquer (or a hard varnish) to protect the printed surface.

Example label for a Semi or Centre axle Trailer

EB+	ADR TÙ.EGG.094-04	4S/2M	S1A S1B	520mm 100t	S2A S2B	520mm 100t
TRAILER MANUFACTURER FABRICANT/RETAILER PROCELSUR DE RE-VILLE	1234567890123456789	BRANCOLOTTA NO. BRUNDEO-NO-SPUNNER CALCULATED IN KG	1234567890123456			
O-DESIGNER FABRICANT/RETAILER NUMERO DE-ACC	12345678901234567	TYPE TIP TYPE	123456789012			
IN-RESHOLD PRESSURE IN-SPRINT PRESSURE IN-SPRINT PRESSURE (bar)	0.20	PRESSURE LENT DRIVE/REBRING LINT DE PRESSOR (bar)	-			
UNLADEN / LEER / A VIDE			LADEN / BELADEN / EN CHARGE			
IN-RESHOLD PRESSURE IN-SPRINT PRESSURE IN-SPRINT PRESSURE (bar)	6.50	IN-RESHOLD PRESSURE IN-SPRINT PRESSURE IN-SPRINT PRESSURE (bar)	0.70	-	-	6.50
AJLELOO AD-LEET O-WEESOR	SUPRESON PRESURE BALCORO/ PRESOR DE SUPRESON (bar)	OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE (bar)	AJLELOO AD-LEET O-WEESOR	SUPRESON PRESURE BALCORO/ PRESOR DE SUPRESON (bar)	OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE (bar)	
1 AXLE 1 AXE 1 ESSOR	3000	0.70	3.00	9000	5.00	0.50 - - 6.50
2 AXLE 2 AXE 2 ESSOR	3000	0.70	3.00	9000	5.00	0.50 - - 6.50
3 AXLE 3 AXE 3 ESSOR	3000	0.70	3.00	9000	5.00	0.50 - - 6.50

To align the print on the blank paper to be within the cut out margins use from the top menu 'File', 'Page Offset' command.




The following screen will appear. Use the vertical/horizontal sliders to make the adjustment for the appropriate printer.

On completion of the label printing Click on button on the appropriate screens return to the main screen.

Example label for **Full Trailer**

EB+	ADR TÙ.EGG.094-04	4S/3M	S1A S1B	520mm 100t	S2A S2B	520mm 100t			
TRAILER MANUFACTURER FABRICANT/RETAILER PROCELSUR DE RE-VILLE	TRAILER EXAMPLE	BRANCOLOTTA NO. BRUNDEO-NO-SPUNNER CALCULATED IN KG	12345						
O-DESIGNER FABRICANT/RETAILER NUMERO DE-ACC	12345	TYPE TIP TYPE	12345						
IN-RESHOLD PRESSURE IN-SPRINT PRESSURE IN-SPRINT PRESSURE (bar)	1 AXLE 1 AXE 1 ESSOR	0.40	2 AXLE 2 AXE 2 ESSOR	0.40	PRESSURE LENT DRIVE/REBRING LINT DE PRESSOR (bar)	1 AXLE 1 AXE 1 ESSOR	8.50	2 AXLE 2 AXE 2 ESSOR	8.50
UNLADEN / LEER / A VIDE			LADEN / BELADEN / EN CHARGE						
IN-RESHOLD PRESSURE IN-SPRINT PRESSURE IN-SPRINT PRESSURE (bar)	6.50	IN-RESHOLD PRESSURE IN-SPRINT PRESSURE IN-SPRINT PRESSURE (bar)	0.70	-	-	6.50			
AJLELOO AD-LEET O-WEESOR	SUPRESON PRESURE BALCORO/ PRESOR DE SUPRESON (bar)	OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE (bar)	AJLELOO AD-LEET O-WEESOR	SUPRESON PRESURE BALCORO/ PRESOR DE SUPRESON (bar)	OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE OUT-RESHOLD PRESSURE (bar)				
1 AXLE 1 AXE 1 ESSOR	2380	0.55	2.10	10000	3.50	0.40 - - 6.85			
2 AXLE 2 AXE 2 ESSOR	1700	0.90	2.10	9000	4.00	0.40 1.40 2.50 6.85			
3 AXLE 3 AXE 3 ESSOR	1700	0.90	2.10	9000	4.00	0.40 1.40 2.50 6.85			

Reset the ECU by clicking button or switch power to the ECU OFF but **DO NOT EXIT THE DIAG+ PROGRAM**



Setting the trailer EBS warning lamp.

After Resetting wait 10 secs before proceeding further. Observe the trailer EBS warning light. The warning lamp should display what has been set in the 'Lamp Setting' section of the ECU Setup.


NB: If the EBS warning light comes ON and stays ON and the main screen displays as on page 6 there are Diagnostic Trouble Codes (DTC) present which need to be cleared see page 22 or if the system air pressure is below 4.5 bar.

Click on the button  on Main screen 'A' also 

on DTC's, Lining Wear and Modification Records screen 'B' to show any stored DTC's

If there are no DTC's detected the following screen will appear.


Click on button  to accept **EXIT THE DIAG+ PROGRAM.**



A




B



Reading/Deleting diagnostic codes

(a) Click on the button  on Main screen also  on DTC's, Lining Wear and Modification Records screen




The following screen's will appear.

Screen Option 1:

If there is a Current DTC it will be displayed in red 1st on the list. If there are other DTC's listed they have been stored in the ECU memory.


Repair the current DTC and re-enter the DTC screen.




Screen Option 2:

If there is NO Current DTC it will display 'No Active DTC's' in Green. Any other DTC's are stored which can be deleted.

(b) Click on the button marked  to delete the Stored DTC's




(c) The following screen will appear. Click button marked  to exit.




The 'DIAG+' main screen will appear.

(d) Reset the ECU by clicking button  or switch power to the ECU OFF but **DO NOT EXIT THE DIAG+ PROGRAM.**



(e) Observe the trailer EBS warning light. The warning lamp should display what has been set in the 'Lamp Setting' section of the ECU Setup.


NB: If the EBS warning light comes ON and stays ON there are DTC's present which need to be cleared as above or if the system air pressure is below 4.5 bar..



The following screen will appear and should display no DTC's


NB: If further DTC's are present repeat procedure (b) to (e)

EXIT THE DIAG+ PROGRAM.



Reading Extended diagnostic codes

On Active and Stored DTC's double click on any DTC and select button  to display the extended DTC information.



The following screen appears.

Understanding the main screen display

55 - The number of times the DTC occurred (Max 255 events). The event is logged every time the ECU is powered.

The following data relates to the 1st time the DTC occurred.

- 56 - Date reading. Recorded when a Info Centre is installed. Updated every 10 mins. (Example shows no Info Centre)
- 57 - Odometer reading (Total distance)
- 58 - Volts Reading
- 59 - Reservoir pressure (Full information available on ECU ver A272 onwards)
- 60 - Suspension bag pressure (Full information available on ECU ver A272 onwards)
- 61 - Speed at which the DTC occurred (Example shows vehicle stationary)
- 62 - Electric control line pressure CAN lines pins 6,7 on ISO 7638 (Example shows a 5 pin ISO 7638 installed)
- 63 - Pressure reading on the Service (Yellow) line while braking.
- 64 - Total time, from ECU power up, when DTC occurred.
- 65 - Flashing Icons:




DTC from ECU



DTC from file

- 66 - Description of DTC
- 67 - Status Flags of signal requests and system information refer to Haldex for further interpretation.
- 68 - Order and quantity of DTC/s
- 69 - Read Extended DTC file from disc
NB: To read this file you must enter the 'Extended DTC Information' screen.
- 70 - Save Extended DTC file to disc.
- 71 - Backward (if more than one DTC)
- 72 - Forward (if more than one DTC)
- 73 - Exit



Reading Lining Wear Sensor

NB: This feature must be set in AUX Configuration - see page 14, AUX 4 -Option.

Click on the button and check if a DTC 'AUX 4' is listed. If identified click on button to enter the lining wear info screen.

The following screen's will appear which lists the history of the changes of Linings (**last five recorded**).

The left hand column records when the brake pads (lining wear sensor) has worn. The right hand column records or indicates when the brake pads have been replaced or require replacing.

If the '**Status of current pads**' indication is coloured **Red** and the Info indicates '**Needs Change**' exit Diag+ switch power off to ECU and repair appropriate lining/s.

Re-enter to Diag+ and '**Lining Wear Info**' screen.

Click button marked

The following screen appears. Click on button marked 'OK'.

The following should occur:

- a) In the Brake Pad Replacements column the 'Needs Change' is replaced by a figure in Km.
- b) The 'Status Of Current Pads' indicator changes from Red to Green.

On 'Lining Wear Info' screen click Button marked to exit to Main screen.


NB: Diagnostic code 'Aux4' is deleted automatically.

When linings are in good condition or to review the 'Lining Wear Info' screen enter as described above.


The following screen will be displayed.

The '**Status of current pads**' indication is coloured **Green**

Record any necessary details for future reference.



Red



Green

Reading Modification Record

Click on the button  on Main screen also 

'BLUE box 'on DTC's, Lining Wear and Modification Records screen



The following screen appears.

This is a record of when the ECU has been programmed.

The user can be the computers name or log on name or 'Info C' representing Info Centre. The display shows up to ten recent users.

Click button marked  to exit.

ECU Modification Records

User	Date	Time
Test	Jan 10 2004	11.30
Test	Jan 09 2004	11.26
Test	Jan 08 2004	11.24
Test	Jan 07 2004	11.22
Test	Jan 06 2004	11.20
Test	Jan 05 2004	11.18
Test	Jan 04 2004	11.16
Test	Jan 03 2004	11.14
Test	Jan 02 2004	11.12
Test	Jan 01 2004	11.10



Reading History of Flash Programming Of ECU


Click on the button  'RED box ' on DTC's, Lining Wear and Modification Records screen

The following screen appears.

Works by displaying the last ten Flash Programming Events, sorted most recent first, in the same manner as DIAG+ Programming Record. When the ECU flash memory is reprogrammed to version B310/B311 or later, a record is made in the ECU memory (containing details of the computer used, the date and the ECU version).

NB: Records from older ECU versions will display a message of 'No data available !' .

Click button marked  to exit.




Prog

User	Date	ECU Ver
Test	Jan 04 2005	B321
Test	Dec 01 2004	B318
----	-----	-----
----	-----	-----
----	-----	-----
----	-----	-----
----	-----	-----
----	-----	-----
----	-----	-----
----	-----	-----




Reading system pressures, speeds and voltage

Connect Emergency and Service pressure lines. Observe the values of the system pressures and voltage on the browser window which shows the schematic of the EB+ system.




Example : the following should be displayed

- 1) *Pressure values are from the Load Plate Data entry shown on page 10 for an **Unladen trailer**. The reservoir pressure is shown as 6.5 Bar minimum but can be whatever is used in the workshop.*




- 2) *Pressure values are from the Load Plate Data entry shown on page 10 for a **Laden trailer**.*



On rotation of the sensed wheels the speed value will be displayed.

Example:

- | | | |
|--------------------------|-------|---------------|
| 1 rev / 2 sec (30 rpm) ≈ | 4 kph | for 80 tooth |
| | 5 kph | for 90 tooth |
| | 6 kph | for 100 tooth |





Clear all Active or Stored Diagnostic Trouble Codes before proceeding with End-of-Line Test.
NB: When the ECU is initially programmed all DTC's are deleted (see Page 22 - Option 2)

End-of-Line Test Procedure

(a) Click on the button  on main screen.

The following screen's will appear.

With the correct interface and ECU versions used **Ensure Warning notes.**

Continue Test, click  to proceed with next step.

The 'View/print'  and 'Save to file'  buttons are initially disabled. They are enabled under the following conditions:-

- a) Completion of an EOLT
- b) An existing EOLT file is opened (.eol) ('View/print' only)

'Embedded Software Version' screen

If the interface or ECU are not compatible (i.e. wrong versions) Click  to quit the EOLT procedure. Update appropriate version.

'WARNING' screen

If there is no pressure measured at PORT 41 check installation piping.

EOLT Initialisation

A listing of tests are shown. The boxes marked indicate the tests to be carried out. The tests can be selected or de-selected as required.

If the **'Pause Between Tests'** option is not selected, the selected tests screen will run automatically after each test has been carried out.

If the **'Operators Name'** option is selected, it will enable a name to be entered in the area below. This will be recorded on the EOLT report.

NB: The Screen display as shown is relevant to a 2 Modulator system. The Sensor-Modulator tests is a combination of the Sensor output to the correct Modulator.

Sensor Test

Rotate each wheel through 3 revolutions in 5 seconds.

Result section:





YELLOW indicates wheel spinning fast enough.

GREEN indicates test passed.

RED indicates DTC generated during test.

NB: On each of the following test screens there is a button marked . This gives on-screen information about test to be carried out.

If the trailer information has been entered (see page 18 - 'Info') with the Vehicle Ident Number then this will be displayed in the title bar of each test as 'VIN 17_figure_chassis'.



Sensor- Modulator Test


Rotate each wheel through 1 revolutions in 2 seconds.
The system should brake the spinning wheel.

Result section:

YELLOW indicates wheel has moved.

GREEN indicates test passed.


RED indicates test failed.



Push Through Pressure Test


APPLY BRAKE

The system should be forced into push-through condition (approx. 1:1) and the delivery pressures will be measured.



RELEASE BRAKE

The TARGET pressure is a calculated value.
The 'Main Valve Port 1' and 2 boxes displays the actual pressure that is measured at the EPRV.
For 3M systems the actual pressure is displayed in the 'Remote Valve' box.



Result section:

YELLOW indicates test started.

GREEN indicates test passed.

RED indicates test failed.

EBS Pressure Function Test (Automatic test)

The system will be forced to simulate various load conditions and control pressures. The delivery pressures will be measured and compared with the target pressures.


Result section:

YELLOW indicates test started.


GREEN indicates test passed.

RED indicates test failed.

NB: The example shows the screen as for a 2M Side by Side installation.
For 3M a two screens appear '3M Master 'and '3M Remote'



NB: Before this test a Warning screen may appear. Make sure that there is the required air pressure in the reservoir to carry out the test. Failure results may occur on the output values (P3) if the value measured (-0.3 bar min.) is below the target value.



Lamp and Auxiliaries Test (Automatic test)

The Cab Lamp and any auxiliaries will be forced ON then OFF, and monitored to determine the correct response. Once correctly tested, the lamp or auxiliary can be switched manually without affecting test results. To switch to manual testing click on the 'On' button the 'Off' and 'Norm' buttons are highlighted, Toggle between the 'On' and 'Off'. The 'Norm' resets to automatic mode.

Result section:

YELLOW indicates test started.

GREEN indicates test passed.

RED indicates test failed.

AUX5 tests the (External) Lateral Accelerometer (EB+ Stability) if selected in the AUX Configuration option (see page 14).

If the test fails refer to EB+ Stability installation Instructions 000 700 287 and check chassis installation.

OR

INT tests the Internal Lateral Accelerometer (EB+ Stability) if selected in the AUX Configuration option '**Internal**' (see page 16).

If the test fails refer to EB+ Installation Instructions 000 700 240 and check chassis installation.

If EITHER Lateral Accelerometer has ALREADY BEEN PROGRAMMED, then an option is given to skip the calibration step, e.g. repeat EOLT no longer on level ground. The following screen appears

Click on button marked to accept.

The following screen appears






EOLT Reports

The End of line Test report can be viewed by selecting the button. If required the report can then be printed.

By selecting the button a report file can be saved.

A file name relevant to the vehicle tested (e.g. TRAILER01 saved as type .eol) can be entered in position '**File Name**' and stored in the **C:\Program Files\Haldex\Diag+\EOLT Reports** folder.

NB: The EOLT report can only be viewed within DIAG+ program in the EOLT section (refer to page 27 - Sec a)



Haldex EB+ End of Line Test Report

HALDEX EB+ END OF LINE TEST REPORT				
ECU Configuration		2S : 2M ECU Right		
Vehicle Ident Number		Not Set		
Manufacturer		Not Set		
ECU Serial Number		B7850_50		
Odometer (km)		0		
Date (DD:MM:YY)		12:01:05		
Time		10:02		
Sensor Tests				Not Applicable
S1A	S1B	S2A	S2B	
-	-			
Sensor-Modulator Tests				Failed
S1A	S1B	S2A	S2B	
Not Applicable	Not Applicable			
Push Through Tests			Not Applicable	
P21(Main)	P22(Main)	P2(Rem)		
-	-			
EBS Pressure Tests				Not Applicable
Test	Target	P21(Main)	P22(Main)	P2(Rem)
Threshold	-	-	-	
PP1 [U]	-	-	-	
PP1 [L]	-	-	-	
PP2 [U]	-	-	-	
PP2 [L]	-	-	-	
PP3 [U]	-	-	-	
PP3 [L]	-	-	-	
Auxiliary Tests				Not Applicable
AUX	TYPE		Result	
Lamp	-		-	
Aux 1	No Aux		-	
Aux 2	No Aux		-	
Aux 3	No Aux		-	
Aux 5	No Aux		-	
Lat Acc Internal	Not Fitted		-	
Operator's Name				
Signature				

If a diagnostic trouble code not listed below is displayed check for intermittent sensor and wiring faults.

DTC DISPLAYED

ECU TIME OUT

or

NO LINK

No supply on ignition switched line.

Possible causes:

Truck fuse blown.

Open circuit B - . ISO7638 not connected

S1A CONT

S1B CONT

S2A CONT

S2B CONT

SENSOR GROUP

1A Sensor/wiring open or short circuit

1B Sensor/wiring open or short circuit

2A Sensor/wiring open or short circuit

2B Sensor/wiring open or short circuit

S1A SIGNAL

S1B SIGNAL

S2A SIGNAL

S2B SIGNAL

INTERMITTENT LOW SENSOR OUTPUT GROUP

1A Sensor signal fault

1B Sensor signal fault

2A Sensor signal fault

2B Sensor signal fault

Possible causes:

Loose sensor, connection, bracket or exciter. Damaged exciter.

Maladjusted sensor or worn sensor cable insulation.

S1A OUTPUT

S1B OUTPUT

S2A OUTPUT

S2B OUTPUT

LOW SENSOR OUTPUT GROUP

1A Sensor system fault

1B Sensor system fault

2A Sensor system fault

2B Sensor system fault

Possible causes:

Sensor worn, maladjusted sensor, wiring open or short circuit

BRK APPLY SC

BRK APPLY OC

BRK APPLY SC DRIVE

BRK APPLY UNSPEC

BRAKE APPLY SOLENOID GROUP

Brake apply solenoid short circuit

Brake apply solenoid open circuit

Brake apply solenoid short circuit permanently energised

Brake apply solenoid control circuit fault

EPRV 21 HOLD SC

EPRV 21 DUMP SC

EPRV 21 HOLD AND DUMP SOLENOID GROUP

Modulator 21 hold solenoid short circuit

Modulator 21 dump solenoid short circuit

EPRV 21 HOLD OC

EPRV 21 DUMP OC

Modulator 21 hold solenoid open circuit

Modulator 21 dump solenoid open circuit

EPRV 21 HOLD SC DRIVE

EPRV 21 DUMP SC DRIVE

Modulator 21 hold solenoid short circuit permanently energised

Modulator 21 dump solenoid short circuit permanently energised

EPRV 21 HOLD UNSPEC

EPRV 21 DUMP UNSPEC

Modulator 21 hold solenoid control circuit fault

Modulator 21 dump solenoid control circuit fault

DTC DISPLAYED

EPRV 22 HOLD SC EPRV 22 DUMP SC	EPRV 22 HOLD AND DUMP SOLENOID GROUP Modulator 22 hold solenoid short circuit Modulator 22 dump solenoid short circuit
EPRV 22 HOLD OC EPRV 22 DUMP OC	Modulator 22 hold solenoid open circuit Modulator 22 dump solenoid open circuit
EPRV 22 HOLD SC DRIVE EPRV 22 DUMP SC DRIVE	Modulator 22 hold solenoid short circuit permanently energised Modulator 22 dump solenoid short circuit permanently energised
EPRV 22 HOLD UNSPEC EPRV 22 DUMP UNSPEC	Modulator 22 hold solenoid control circuit fault Modulator 22 dump solenoid control circuit fault
DEMAND SC DEMAND OC	DEMAND PRESSURE TRANSDUCER GROUP Service line pressure transducer short circuit Service line pressure transducer open circuit
EPRV 21 DEL SC EPRV 21 DEL OC	DELIVERY PRESSURE TRANSDUCER GROUP Modulator 21 delivery pressure transducer short circuit Modulator 21 delivery pressure transducer open circuit
EPRV 22 DEL SC EPRV 22 DEL OC	Modulator 22 delivery pressure transducer short circuit Modulator 22 delivery pressure transducer open circuit
EPRV 21 SLOW REC EPRV 22 SLOW REC	ONE WHEEL WITH SLOW RECOVERY GROUP Slow recovery of one wheel of modulator 21 Slow recovery of one wheel of modulator 22 Possible causes: Slow brake release, foundation brake mechanical faults, dry bearings, broken spring, restricted piping Check for kinks and blockages etc. Incorrect piping, Wiring. Modulator fault. Sensor wiring crossed across an axle.
RESR SC RESR OC HIGH RES PRESURE	RESERVOIR PRESSURE TRANSDUCER GROUP Reservoir pressure transducer short circuit Reservoir pressure transducer open circuit Reservoir pressure above 9.5 bar
SUSP SC SUSP OC SUSP LOW	SUSPENSION PRESSURE TRANSDUCER GROUP Suspension pressure transducer short circuit Suspension pressure transducer open circuit Suspension pressure values outside operating range
REV SWITCH SC REV SWITCH OC REV SWITCH PNEUMATIC REV SWITCH SIGNAL	PRESSURE SWITCH GROUP Relay emergency valve pressure switch short circuit Relay emergency valve pressure switch open circuit Relay emergency valve pressure switch pneumatic fault Relay emergency valve pressure switch failed to activate

DTC DISPLAYED

**PNEUMATIC DEMAND LOSS
TOWED CAN DEMAND LOSS
TOWED CAN CONTROL LOSS**

ISO11992 (CAN) ELECTRICAL SIGNAL GROUP

No corresponding pneumatic demand pressure
CAN line (pin 6 and 7 on ISO7638) fault
CAN line (pin 6 and 7 on ISO7638) data fault

**PWR ISO7638 FAIL
PWR LO VOLT**

SUPPLY VOLTAGE GROUP

Power loss on pin 1 or 2 (ISO7638)
Supply voltage at ECU less than 19v when brake apply solenoid energised

**PWR HI VOLT
PWR UNSPEC**

Supply voltage at the ECU greater than 32v
Internal ECU fault

**ECU EEERR
ECU PARAMERR
ECU EE UNSPEC**

ECU GROUP

Internal ECU fault or ECU not programmed
Internal ECU fault or ECU not programmed
Internal ECU fault or ECU not programmed

**AUX1
AUX2
AUX3
AUX4
AUX5**

AUXILIARY COMPONENTS GROUP

Auxiliary 1 system/wiring open or short circuit
Auxilliary 2 system/wiring open or short circuit
Auxilliary 3 system/wiring open or short circuit
Auxilliary 4 system/wiring open or short circuit
Auxilliary 5 system/wiring open or short circuit

BRAKE PADS

LINING WEAR GROUP

Lining wear wiring open circuit

**LAT ACC OC
LAT ACC SC
LAT ACC SIGNAL**

LATERAL ACCELEROMETER

Lateral accelerometer wiring open circuit
Lateral accelerometer wiring short circuit
Lateral accelerometer signal fault

**SLAVE VALVE SENSOR
SLAVE VALVE MODULATOR
SLAVE VALVE CABLE
SLAVE VALVE SLOW REC
SLAVE SUSP LOW**

SLAVE VALVE GROUP

Pressure transducers open or short circuit
Hold, Dump or Brake Apply solenoid open or short circuit
Link cable open or short circuit
Slow recovery of one wheel of slave valve
Suspension pressure values outside operating range

Note: If a DTC is displayed and after following recommended procedure the ECU should be replaced.

Screen 1

On appearance of this screen the following areas need to be checked:


- a) The receive and transmit buffers have been disabled on your PC. Check the COM port properties.
- b) Another program that uses the COM port is open. Check the bottom of your PC screen and close any other programs.



Screen 2



On appearance of this screen the following areas need to be checked:

- a) Connections loose. Check that each plug is firmly connected.
- b) LED light off on PC Interface pod. Check power supply to the ECU from the ISO7638 (or similar 24v supply) is on.



Screen 3

On appearance of this screens the system is still in system supplier mode (i.e. a command was requested within 10 secs of clicking the Reset button (Page 4, button '20').
Switch power OFF and ON to trailer.



If you do have problems, please contact the **HALDEX DIAG+** Helpdesk on +44 1527 499 499.

Austria

Haldex Wien Ges.m.b.H
Vienna
Tel: + 43 1865 16 40
Fax: + 43 1865 16 40 27
e-mail: office@baeder-haldex.at

Belgium

Haldex N.V./S.A
Balegem (Ghent)
Tel: + 32 9 363 90 00
Fax: + 32 9 363 90 09
e-mail: info.hbe@haldex.com

Brazil

Haldex do Brazil
São Paulo
Tel: + 5511 5034 4999
Fax: + 55 11 5034 9515
e-mail: info@hbr.haldex.com

China

Haldex International Trading Co. Ltd.
Shanghai
Tel: + 86 21 6289 44 69
Fax: + 86 21 6279 05 54
e-mail: info@hcn.haldex.com

France

Haldex Europe S.A.R.L.
Weyersheim (Strasbourg)
Tel: + 333 88 68 22 00
Fax: + 333 88 68 22 09
e-mail: info.heu@haldex.com

Germany

Haldex Brake Products G.m.b.H
Denkendorf (Stuttgart)
Tel: + 49 711 934 917 0
Fax: + 49 711 934 917 40
e-mail: info@hde.haldex.com

Haldex Brake Products G.m.b.H
Heidelberg
Tel: + 49 6221 70 30
Fax: + 49 6221 70 34 00
e-mail: info@hbpde.haldex.com

Great Britain

Haldex Ltd.
Newton Aycliffe
Tel: + 44 1 325 310 110
Fax: + 44 1 325 311 834
e-mail: aycliffe.info@haldex.com

Haldex Brake Products Ltd.
Redditch
Tel: + 44 1527 499 499
Fax: + 44 1527 499 500
e-mail: redditch.info@haldex.com

Hungary

Haldex Hungary Kit.
Szentlorincskata
Tel: + 36 29 631 300
Fax: + 36 29 631 301
e-mail: info.hu.eu@haldex.com

India

Haldex India Ltd.
Nasik
Tel: + 91 253 2380094
Fax: + 91 253 2380729
e-mail: haldex@haldexindia.com

Italy

Haldex Italia Srl.
Muggiò (MI)
Tel: + 39 039 278 23 50
Fax: + 39 039 796 525
e-mail: info@hit.haldex.com

Poland

Haldex Sp z o.o.
Praszka
Tel: + 48 34 350 11 00
Fax: + 48 34 350 11 11
e-mail: info@haldex.net.pl

South Korea

Haldex Korea Ltd.
Seoul
Tel: + 82 2 2636 7545
Fax: + 82 2 2636 7548
e-mail: info@hkr.haldex.com

Spain

Haldex España S.A.
Parets del Valles (Barcelona)
Tel: + 34 93 573 10 30
Fax: + 34 93 573 07 28
e-mail: haldexespana@haldex.es

Sweden

Haldex Brake Products AB
Landskrona
Tel: + 46 418 47 6000
Fax: + 46 418 47 6001
e-mail: info@hbpse.haldex.com

USA

Haldex Brake Products Corp.
Kansas City MO
Tel: + 1 816 891 2470
Fax: + 1 816 891 9447
e-mail: hbsna@haldex.com

Company Vision

We use our demonstrated competence to provide innovative components, systems and service for trucks, trailers and buses, that lower life cycle costs and improve vehicle safety. Haldex wants to become the first choice business partner of commercial vehicle manufacturers world wide in the areas of braking and suspension control systems with special emphasis on heavy commercial vehicles.

Total Support

A uniquely wide range of services is available from Haldex. These include expert consultancy for braking and suspension development, brake calculations, type approvals and application engineering.

The aim is accurate specification for manufactures and low cost of owner ship for the operator.

Full aftermarket support includes a Worldwide parts distribution and service network, on-line technical advice, field visits and installation/ maintenance training held on-site or at Haldex facilities.

Research and Development

Continual, heavy investment in Research and Development is carried out in response to ever increasing commercial, legislative, environmental, performance and technological demands.

Quality and Production Standards

The very latest production technology ensures the very highest quality standards. All production sites are ISO 9001 approved.



The Haldex Group is a global supplier of proprietary products for trucks, cars and industrial vehicles, with special emphasis on performance and safety. The Group is organized in Divisions which focus on their respective product niche:

Haldex Brake Systems supplies ABS and brake components for heavy vehicle air brakes.

Haldex Barnes Hydraulics supplies gear pumps and hydraulic systems for power steering and lifting functions on industrial vehicles and trucks.

Haldex Garphyttan Wire supplies specially steel-alloyed wire products mainly for applications in combustion engines.

Haldex Traction Systems supplies 4WD systems for cars and trucks.

Sales companies are established in Europe, North and South America and Asia. Production takes place in 9 factories in USA, 9 factories in Europe and 1 joint venture in India.

The Haldex Group is listed on the Stockholm Stock Exchange.



www.brake-eu.haldex.com